

KinderSign – Clean and Disinfect your Tablets

We recommend that you maintain your tablets clean and sanitized at all times.

We also recommend using 70 percent alcohol wipes or Clorox Disinfecting wipes when sanitizing your tablet and following these guidelines:

- To clean your tablet, use only a soft, lint-free cloth. Avoid using abrasive cloths, towels, paper towels, or similar items.
- Unplug all external power sources, devices, and cables.
- Gently wipe the hard, non-porous surfaces of the tablet.
- Avoid excessive wiping, which might cause damages.
- Keep liquids away from the product, unless otherwise noted for the specific cleaning products you are using.
- Do not allow moisture into any openings.
- Do not use aerosol sprays, bleaches, or abrasives products.
- Do not spray cleaners directly into the tablet.
- Do not submerge your tablet in any cleaning product.
- Do not use bleach.

Note: These recommendations do not apply to sanitizing fabric or leather surfaces.